



Technical Guide

Creating a backup on Integra32

Go into the Integra Software and select **Tools** at the top of the page, then click **Backup**.

🕒 Integra32 - A	AxiomLite Securit	y System
-----------------	-------------------	----------

General	Options	Database	Tools	Add-ins	
9	8	<u></u>	2		
Backup	Void Cards	Finger Print	Query FPR	Badge Designer	
Backu	p	Log message			
08/10	/2020 10:19:54	Server online (Site : Default)		
08/10	08/10/2020 10:19:54 Audit message: Operator logged on rbh				
80					

Select Run backup now and click Next.

Integra32 - AxiomLite Backup Configuration Wizard			
This wizard will help you to bac	skup Integra32 data files.		
	 Run backup now Configure auto-backup 		
Cancel	< <u>B</u> ack <u>N</u> ext > <u>F</u> ini	sh	

The **destination location** should look like the default one below. If you want to backup everything, tick all the files. (You can backup to a network location or memory stick as long as you have admin privileges).

Integra32 - Axi	iomLite Backup Configuration Wizard	×
	Select destination folder C:\Program Files (x86)\rbh\Integra32\Default\Backup\ Select the file(s) to backup.	
Cancel	< <u>B</u> ack <u>N</u> ext> <u>F</u> inish]


If you the backup is successful, the **Event log** should display the messages below.

_		-					
I	Ge	neral	Options	Database	Tools	Add-ins	Repor
		9	8				
	В	ackup	Void Cards	Finger Print	Query FPR	Badge Designer	r Cust
		Date		Log message			
		08/10/202	0 10:19:54	Server online (Site : Default)		
		08/10/202	0 10:19:54	Audit message:	Operator logge	don rbh	
		08/10/202	0 10:24:37	System: Backup	started C:\Pro	gram Files (x86)\rt	h\Integ
		08/10/202	0 10:24:37	System: Backin	g-up file Axuser	LT.mdb	
		08/10/202	0 10:24:38	System: Backin	g-up file Axsysti	LT.mdb	
	5 0	08/10/202	0 10:24:38	System: Backin	g-up file Axlogx	LT.mdb	
	1 <u>2</u>	08/10/202	0 10:24:38	System: Backin	g-up file Images	:	
	ent log	08/10/202	0 10:24:38	System: Backup	o ended C:\Prog	gram Files (x86)\rbl	h\Integi

Integra32 - AxiomLite Security System

We also recommend setting up a scheduled backup, please see below.

Repeat step 1, but instead of Run backup now, select Configure auto-backup and click Next.



Leave the destination folder location as the one shown below and elect the files that you want to backup.

Integra32 - AxiomLite Backup Configuration Wizard			
	Select destination folder C:\Program Files (x86)\rbh\Integra32\Default\Backup\ . Select the file(s) to backup.		
	 ✓ Data Files ✓ History Files ✓ Cardholder Image Files 		
Cancel	< <u>B</u> ack [<u>Next</u> >] Einish		

Here, you can select the time and days you want to backup your files. Below is an example of a backup scheduled for Monday, Tuesday, Wednesday and Thursday at 1am. Click **Finish** when completed.

Integra32 -	AxiomLite Backup Configuration Wizard	×
	Select the time and day(s) to run the backup 01:00:00 Sun Mon Tue Wed Thu Fri Sat	
	365 -	
Cancel	< <u>B</u> ack <u>N</u> ext > <u>F</u> inish	