

UNC500

HARDWARE MANUAL

**new generation
building security**



Copyright Notice

Copyright© 1995-2012 by RBH Access Technologies Inc.

All rights reserved Worldwide. Printed in Canada. This publication has been provided pursuant to an agreement containing restrictions on its use. No part of this book may be copied or distributed, transmitted, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, manual, or otherwise, or disclosed to third parties without the express written consent of RBH Access Technologies Inc., Mississauga, Ontario, Canada.

Trademark

AxiomV™ is the trademark of RBH Access Technologies Inc. Windows is a trademark of Microsoft Corporation. All other product names mentioned herein are the property of their respective owners. Use of a term in this book should not be regarded as affecting the validity of any trademark or service mark.

Disclaimer

This book is provided *as is*, without warranty of any kind, either express or implied, including but not limited to performance, merchantability, or fitness for any particular purpose. Neither RBH Access Technologies Inc. nor its dealers or distributors shall be liable to any person or entity with respect to any liability, loss, or damage, caused, or alleged to have been caused directly or indirectly by this information. Further RBH Access Technologies Inc. reserves the right to revise this publication, and to make changes to the content hereof from time to time, without the obligation of RBH Access Technologies Inc. to notify any person or organization of such revision or changes.

RBH ACCESS TECHNOLOGIES INC.
2 Automatic Road, Suite 108
Brampton, Ontario
CANADA
L6S 6K8

Contents

INTRODUCTION.....	4
COMMUNICATION.....	4
NETWORKS	4
OUTPUTS.....	4
AUXILIARY POWER.....	4
INPUTS	4
READER INTERFACE	5
BATTERY CHARGER.....	5
REVERSE BATTERY PROTECTION	5
BATTERY TEST	5
FUSE MONITORING.....	5
DIAGNOSTIC LED'S.....	5
TAMPER DETECTION	5
RAM MEMORY.....	6
FLASH MEMORY	6
UNC500 CONTROLLER	7
CONNECTION DETAILS	9
DIP SWITCH SETTINGS	9
PC CONNECTION	11
CNET (CONTROLLER NETWORK)	14
D-NET DEVICE NETWORK	16
INPUTS	19
OUTPUTS.....	23
ACCESS POINT OPERATING MODES	24
READER CONNECTION.....	25
NRC2000 & NURC2000	26
MODIFICATION	26
UNC500 SPECIFICATION	27
CABLE SPECIFICATION	28

Introduction

The UNC500 has been designed to take over the functionality of the Axiom NC100 (network controller), an RC-2 (reader controller) and an LIF (local area network interface). The network interface can also contain a POE (power over Ethernet) converter.

Communication

The UNC500 has three RS485 ports and an Ethernet 10/100 interface. Depending on the hardware configuration all three channels may not be available. Communications from the host computer running Axiom software can be achieved in the following ways; either via Ethernet through a socket interface or via RS485 through a direct connection to a designated channel. The Ethernet interface may be single or dual ported 10/100 Mbs, depending on how the board is configured. The UNC500's RS485 channels 1, 2, or 3 may be programmed as 'HOST', 'DNET', 'NCNET', or 'CNET'. Use the DIP switch to select baud rate for Host communications as 9600, 38400, 57600, or 115200.

Networks

There are three networks supported by the UNC500 these are:

- 1) **Host Communications** through the Ethernet or direct connection.
- 2) **Device Communications** for devices such as additional RC-2s starting at address 2, Alarm Keypads, IOC-16 controllers, and PC100.
- 3) **Controller Communications** for controllers such as additional UNC500s or for NC100s via:
 - a. **NCNET** a protocol designed for RS485 communications between UNC500's only.
 - b. **CNET** for connection with NC100's.

Outputs

There are four form C relays and four open collector outputs that can be programmed as general purpose or default applications. Although the contacts are rated at 12 amperes at 125vac the surge protectors prevent voltages greater than 40vac or 56vdc from being applied. The recommended use of the relays is to provide isolated outputs for driving electric strikes or magnetic locks at a maximum voltage of 24v. The open collector outputs are current limited to 100 milli-amperes direct current only.

Auxiliary Power

A thermal fuse protected power output rated at 500 milli-amperes 12Vdc.

Inputs

There are eight inputs used for sensor connections. Four are configured as general purpose and four are either programmed for default application or for general purpose. The software provides configuration information used to decode the state of the contacts. The following table illustrates the seven circuit type assignments. Note that when an input is armed it will only report alarm or restore states. All "normal" states are translated to "restore" and all other states are translated to "alarm".

Reader Interface

Two standard wiegand interfaces provide the following connections for typical proximity readers:

- 1) Thermal fuse protected power (500ma @ 12vdc).
- 2) Wiegand data interface.
- 3) Reader tamper input (s). Initially if open it will be ignored but once a short is connected it will report a reader tamper alarm whenever the input is opened.
- 4) LED and beeper outputs are open collector current limited to 100ma.

Battery Charger

The battery charger routes input power from the 12v input source or 15V POE module through a series power resistor (24 Ω) and constantly monitors the battery voltage. If the battery voltage exceeds 13.8v the battery charger turns off until the voltage has reached 12v. If the battery terminals are not connected this could lead to a constant pulsing of the battery charger output and reporting the battery state as battery – low, battery – normal. To prevent this from happening the battery test cycle is initiated when ten cycles are counted. If the battery test fails the charger is turned off until a power failure is detected or a battery is re-applied.

Reverse Battery Protection

A combination of a three ampere diode and a 1.6 amp thermal fuse protects against accidental connection of a battery in the reverse direction.

Battery Test

A battery test cycle is operator initiated or scheduled. When initiated the charger is turned off and a 24 Ω resistor provides a load to the battery for about ten seconds. If during this period the voltage drops below 10 volts a battery alarm message is sent to the host, otherwise a battery normal message is sent.

Fuse Monitoring

Besides monitoring the battery voltage the UNC500 also monitors the input voltage (DC), auxiliary voltage (aux) and the reader voltage (reader) and reports to the host whenever the state changes.

Diagnostic LED's

Each RS485 circuit has a red and green LED to indicate when a signal is received or transmitted.

Diagnostic 1 is a bicolour LED when red indicates receiving data from the host and when green indicates transmission of data.

Diagnostic 2 will flash slowly when connected to the host and quickly when not connected.

Diagnostic 3 will flash when a power problem such as a low battery or low auxiliary power is detected.

Tamper Detection

A tamper wire may be connected to JP1 located close to the power resistors on the board. A short to this input is normal and an open is alarm.

RAM Memory

The static ram memories hold the database from the host that is downloaded using Axiom software. The coin cell provides power to these memories as well as the real time clock.


Flash Memory

The UNC500 also has flash memory that is used for set-up parameters and firmware. Firmware may be upgraded using two methodologies for the whole application or just the formats. To upgrade the whole application the software will select the network controller and pass an RBH file. To upgrade just the formats the software will select the first RC-2 device and pass a different RBH file.


UNC500 Controller

The AxiomV™ access control system consists of one or more network controllers (**NC-100** or **UNC500**). All information required by the controller is downloaded from the PC and stored locally non-volatile flash memory. This information includes configuration data, cardholder records, access levels, schedules, and all other records necessary for the operation of the system. The controller operates independent of the PC and all decision-making is performed locally, even in the event of total power loss. The UNC500 contains a powerful 32-bit micro-controller and has either 2Mb, 4Mb, or 8Mb of RAM.

UNC500 Silkscreen Legend



Chassis Mount



Rack or Cabinet Mount

Connection Details

Power Input

The UNC500 controller requires 13.8vdc to be supplied from an external source.

CH1 RS485 (HOST)

The Host port connects the UNC500 to a PC through an RS485 interface.

CH2 RS485 (D-NET)

The D-NET (*Device Network*) connects local device controllers (*RC-2, IOC-16, SafeSuite Panels, NRC2000, or NURC2000*) to the UNC500 controller on a high-speed bi-directional RS485 network. Connect CH2 on the UNC500 to CH1 on the first device controller, and then connect it to CH1 on the next device controller on the D-NET and so on. (*see the D-NET diagram on page16*)

CH3 RS485 (NCNET)

The NCNET (*Controller Network*) connects the UNC500 controller to other on a high-speed bi-directional RS485 network. CH3 on the master controller connects to CH3 on the next UNC500 on the network or to CH1 on the next NC-100 controller in the network (*if the Arcnet option is added*). (*see NCNET diagram on page14.*)

DIP Switch Settings

The UNC500 DIP switch controls the device's address and serial port baud rate. The system must be powered down if the controller address is changed using DIP switches 1 through 5. DIP switch changes for a change in baud rate are processed immediately and do not require a power down.

Note: To Reset Panel – All DIP switches must be off.

DIP Switch	
DIP Switch	Function
1 - 5	Controller Address
6,7	Controller Baud Rate
8	<i>not used</i>

Controller Addressing

Use DIP switches 1, 2, 3, 4, and 5 to select the controller address. The address is binary coded and the switch settings for all fifteen possible addresses are given below. The fifth DIP Switch is not usable at this time.

Controller Addressing				
Switch 1	Switch 2	Switch 3	Switch 4	Address
On	Off	Off	Off	1 (Master)
Off	On	Off	Off	2 (Slave)
On	On	Off	Off	3 (Slave)
Off	Off	On	Off	4 (Slave)
On	Off	On	Off	5 (Slave)
Off	On	On	Off	6 (Slave)
On	On	On	Off	7 (Slave)
Off	Off	Off	On	8 (Slave)
On	Off	Off	On	9 (Slave)
Off	On	Off	On	10 (Slave)
On	On	Off	On	11 (Slave)
Off	Off	On	On	12 (Slave)
On	Off	On	On	13 (Slave)
Off	On	On	On	14 (Slave)
On	On	On	On	15 (Slave)

Master Controller

Each network must have a single unit designated as the master controller. The master controller connects to the PC. Setting the DIP switch address to 1 will automatically designate a unit as the master controller.

Slave Controller

All controllers addressed 2 through 15 are referred to as slave controllers.

CH1 RS485 Port Baud Rate Selection (Master Only)

The controller's serial port baud rate is set with controller DIP switches 6 and 7. This setting determines the speed used to communicate with the PC; the controller baud rate must be the same as the baud rate set for the port within the AxiomV™ software. The default baud rate is 9600.

Controller Baud Rate Selection		
DIP Switch 6	DIP Switch 7	Baud Rate
OFF	OFF	9600
ON	OFF	38400
OFF	ON	57600
ON	ON	115200


PC Connection

The master controller is connected to either a serial port on the PC or through the local Ethernet via a static IP address. The means of communication is configured in the AxiomV™ software under *Network Properties/Port Type*.

RS485 Connection

The RS485 interface allows the distance between the controller and the PC to be up to 4000 feet (*1200 meters*) at 38.4k baud. RS485 requires a twisted pair cable 22AWG. Termination is built into the UNC500 and the USB-RS485 module.

PC to UNC500 Connection – RS485 Wiring



Cable Specification

Twisted pair, shielded, 18 to 22 AWG


Maximum Cable Length

4000 feet (*1200 meters*)

UNC500 TCP/IP Connection

The master controller in some installations may not be directly connected to the PC and may be linked by the local Ethernet. The system supports a static IP address only [default address is 192.168.168.125]. To change the IP address of the unit you can either use IPLocator [a utility program provided by RBH] or Telnet.

PC to UNC500 Connection - LAN



Telnet

To program the UNC500 through Telnet you first have to set all DIP switches off. Connect to the panel with an Ethernet cable and configure your computer to have IP address 192.168.168.20 [**remember to reconfigure your machine's IP address back when you are done**]. In the 'cmd' window type the following 'telnet 192.168.168.125'. If a connection is made the following message will be displayed.

Telnet Opened on port 23

2 MEG RAM detected.


A password is required in order to change user parameters. The default password is 'password'. The password can be changed by the user. After entering the password the following items are available for the use to alter.

Name	Defaults	Description and notes
IP ADDRESS	192.168.168.125	Local Ethernet address.
SUBNET MASK	255.255.255.0	Local Ethernet mask
IP GATEWAY	0.0.0.0	For future use when DNS option becomes available.
PORT NUMBER	3002	Primary port number.
ALT PORT NUMBER	3003	Alternate port number applies to "LAN" application.
CH1 APPLICATION	HOST	Com channel #1 application located on the side opposite the power input.
CH2 APPLICATION	DNET	Com channel #2 application located below #1.
CH3 APPLICATION	NCNET	Com channel #3 application located on the same side as the power input. To use this channel the three jumpers must be in the "r" position. If you are using the legacy "C-NET" this value must be "NONE".
Telnet Password	password	This is a string of up to 10 characters that allows the user access to this program.


CNET (Controller Network)

Up to fifteen network controllers can be linked together and feed into a single communication port on the PC. Controller number 1 is designated the master controller and may be connected to the PC using serial or TCP/IP communications. The remaining controllers are referred to as slaves and can only communicate to the PC through the master unit.

NCNET (Controller Network)




CNET (Controller Network)



UNC500 controller can only be connected to NC-100 controller if the Arcnet option has been added [C-Net]. To get the Arcnet to function you need to set jumpers JP5, JP6, & JP7 to 'A' (*for Arcnet*), and configure CH3 in the Telnet setup to be 'none'.



When combining UNC500s and NC100s; connect CH2 of the previous panel and CH1 of the next panel to CH3 (C-NET) of the UNC500. Since the C-Net is a loop; the previous panel to the first panel is the last panel, and the next panel from the last panel is the first panel.



NCNET Cable


Use 20 to 22 AWG shielded stranded twisted pair cable for all C-NET connections.

NCNET Maximum Cable Length

The maximum distance for any link in the C-NET is 2500 feet (760 meters) and the total length cannot exceed 10000 feet (3000 meters).

D-NET Device Network

Up to four RC-2 reader controllers, and up to sixteen IOC-16 input/output controllers, may be connected to each network controller in the C-NET using high speed RS485 communications.



NRC2000 panels may be used in place of RC-2 panels.




NURC2000 may also be used in place of RC-2 panels.



The D-NET connects IOC-16, RC-2, SafeSuite™ panels, PC-100, NRC2000, and NURC2000 devices in a daisy chain fashion (parallel connection) to the network controller. Device controllers do not have to be addressed sequentially. However, using sequential device controller addressing is recommended as this makes your cabling diagrams easier to follow and simplifies troubleshooting as the devices are in the correct numerical sequence.

Device Controller Address Assignment	
Address	Device Controller
1 – 4	RC-2, NRC2000, NURC2000
5 – 20	IOC-16, PC-100
1-255	SafeSuite™ panel

D-NET (Device Network) Connection Example



D-NET Maximum Cable Length

The maximum distance for any link is 3000 feet (*900 meters*) and the total length cannot exceed 15,000 feet (*4600 meters*).

D-NET Cable

Use 20 to 22 AWG shielded twisted pair cable for all D-NET connections. Shielded cable is recommended to minimize problems that can arise in electrically noisy environments. In addition, shielded cable may be necessary to prevent the network from interfering with signals on other cables in the same trunk.

Inputs

The UNC500 has eight fully supervised inputs, four on side A and four on side B. Each input is individually programmable from the PC. The UNC500 employs digital filtering to eliminate the effect of interference on the input loops and verifies all loop changes before reporting to the controller. Loop resistance is continuously monitored using a built in eight bit analog to digital converter and can be viewed from the PC, providing the service technician with a valuable diagnostic tool and allowing marginal circuit loops to be detected and repaired before a full blown fault develops.

Each input has four states: Restore, Alarm, Trouble, and Illegal. Trouble is reported if a short or break is detected on a supervised circuit and illegal is reported if the measured loop resistance lies between valid states. For example, if the circuit type is programmed as '2 resistor normally closed', 1k represents a restored state and 2k represents an alarm state. If the loop resistance changes by more than 15% but not enough to enter the next state, an illegal state is reported.

Request to Exit (Input IN1A, IN5)

The Request to Exit [RTE] input is connected to a push button mounted on the door or to a motion detector mounted near the door. A normally open or normally closed button can be used and the circuit type can be programmed from the PC. Activating the RTE input will unlock the door. The RTE can be disabled by time zone. This input can be used as a general purpose input if RTE operation is not required. If not used, leave the default RTE settings in the AxiomV™ software configuration.

Door Contact (Input IN2, IN6)


The Door Contact [DC] input monitors the state of the door. Forced entry, door held open alarm, and door held open warning require monitoring of the door state. This input can be used as a general-purpose input if the door contact is not required. If not used, leave the default RTE settings in the AxiomV™ software configuration.

Input Circuit Types

The RC-2 supports seven different input circuit types ranging from no resistor for low security applications to two resistor normally closed circuits where the highest security is required.

Normally Closed, No Resistor

Loop Resistance	State
Short	Restore
Open Circuit	Alarm




Normally Open, No Resistor

Loop Resistance	State
Short	Alarm
Open Circuit	Restore




Normally Closed, One Resistor

Loop Resistance	State
Short	Trouble
1k	Restore
Open Circuit	Alarm




Normally Closed, Two Resistor	
Loop Resistance	State
Short	Trouble
1k	Restore
2k	Alarm
Open Circuit	Trouble




This circuit provides a high degree of supervision and detects both short and open circuit fault conditions. Use this circuit in high security applications.


Normally Open, One Resistor	
Loop Resistance	State
Short	Alarm
1k	Restore
Open Circuit	Trouble



Normally Open, Two Resistor	
Loop Resistance	State
Short	Trouble
1k	Alarm
2k	Restore
Open Circuit	Trouble



Normally Open And Normally Closed, One Resistor	
Loop Resistance	State
Short	Alarm
1k	Restore
Open Circuit	Alarm



This circuit type is used where normally open and normally closed contacts are used in the same loop.

Outputs

The UNC500 has eight outputs, four on side A and four on side B. The Lock and Forced/Tamper outputs are dry contact relays capable of switching 12Amps@125vac. The Door Held Open and Alarm Shunt outputs are electronic drivers and can switch 100ma. Outputs are programmable from the PC as normally energized or normally de-energized. Normally energized outputs are used for fail-safe operation where it is essential that the output return to a safe state when the system fails due to power loss, communications failure, or fire.

Electronic outputs are 'switched negative' which means that they switch the power negative to the terminal. When the output is off, the output terminal is electronically disconnected. Outputs can be programmed to operate in a default mode described below or they can be used as general-purpose outputs. However, the output definition in the AxiomV™ configuration software should never be left blank. If the output is unused, use the default output definitions provided in the AxiomV™ configuration software.

Switching Inductive Devices (Locks, Bells)

Exercise caution when switching an inductive load. Inductive devices include external relay, solenoids, bells, and door locks. All of these devices generate extremely high voltage spikes (*several thousand volts*) when applied power is removed. Possible disruption of operation could occur if this interference gets on to the electronic circuit board.

This interference can be suppressed by placing a diode (*1N4001 or similar*) across the lock or other inductive device being switched. Connect the diode cathode (*end with band*) to the positive terminal and the other end to the negative terminal. The diode must be placed at the device being switched and not at the controller.

Default Output Operation

Lock Output (Relay Output)

For magnetic locks, the relay should be configured from the PC as On State de-energized for fail-safe operation. If power fails (*AC and battery*) or the fire input is released, the power to the magnetic lock is removed and the door is opened.

Forced / Tamper (Relay Output)

The Forced/Tamper output turns on if the door is forced open or if a reader tamper is detected. This output remains on for as long as the alarm condition exists.

Door Held Open (Electronic Output)

The Door Held Open output turns on if the door is held open longer than the programmed limit. This output remains on until the door closes. During the warning period, this output will pulse every second.

Alarm Shunt (Electronic Output)

The alarm shunt output turns on when the door is unlocked. This output turns off when the door is re-locked if the door is closed at that time; otherwise the output turns off when the door closes. Normally the shunt output is used to bypass a door contact monitored by a secondary alarm panel.

Access Point Operating Modes

Two Person

The Red LED flashes slowly.

In Two Person Mode, two valid cards are required for access. The reader Buzzer beeps rapidly after the first card is presented. A second valid card must be presented within ten seconds for access to be granted.

High Security

The Red LED flashes quickly.

In High Security Mode, only cardholders with *High Security Privilege* are allowed access.

Unlocked

The green LED turns on to indicate the door is unlocked.

Tamper

The Buzzer sounds continuously.

Lockout Alarm

The Buzzer beeps rapidly.

A lockout alarm occurs when a user-defined number of 'Access Denied' messages occur. These messages can include 'Invalid Card Number', 'No Access at this Time', 'No Access at this Reader', or 'Invalid PIN Code'.

Door Held Open Warning

The Buzzer beeps slowly.

Door Held Open Alarm

The Buzzer sounds continuously.

Keypad / Reader Combination

The Buzzer emits a short beep every second after a card is presented, until a PIN is entered.

Access Granted


The Buzzer emits one long beep and the green LED turns on for the duration of the unlock time.

Access Denied

The Buzzer emits two short beeps and the red LED flashes twice.

Reader Connection

RC-2 to 12-Volt Reader Connection Diagram¹



Cable Specification

7-conductor², stranded, shielded cable (*not twisted*), 20 to 22 AWG

Maximum Cable Length

22 AWG Cable: 250 feet (*75 meters*)

20 AWG Cable: 500 feet (*150 meters*)

¹ Reader wire colours may vary for different reader manufactures. Please verify your wiring.

² Some readers only require 6-conductors since they only have one LED wire (wired to GRN).

NRC2000 & NURC2000

The NRC2000 uses an IRC2000 board and the NURC2000 uses a URC2000 board to provide most of the functionality of the RC2 board to the Axiom system. The NRC2000 and NURC2000 firmware is based on RC firmware so that they will have the same features (as much as possible).

Modification

Due to the lack of internal power supply and fewer I/O lines the NRC2000 and NURC2000 do not provide the following functionality:

Reader Tamper

The reader tamper inputs can be used to monitor AC failure and low battery. Reader “A” tamper is used for AC voltage detection and should be shorted to ground to avoid “AC FAIL” message, if the power supply modifications are not done. Reader “B” tamper is used for battery voltage detection and should be left open to avoid the “BATTERY FAIL” message, if the power supply modifications are not done.

Cabinet Tamper

Cabinet Tamper always reports normal.

Fuse monitoring

Due to the lack of a power supply Fuse Monitoring always normal.

Dual RS485 Redundant Communications

Both panels only have a single channel so they must be wired differently.

Technical bulletin TB53 will show how to modify the NRC2000 board and how to connect to the power supply to monitor for ‘Battery Low’ and ‘AC Failure’.

UNC500 Specification

Controller Power Requirements: 9 – 14vdc

Current Consumption: 250mA

Processor: 32 bit micro controller

Flash ROM: Download firmware upgrades from the PC to UNC500

Memory: 2M, 4M, or 8M

System Capacities: Units C-NET Network Maximum of 15
RC-2 Controllers per network control 4 (*8 card readers*)
IOC-16 Controllers per network control (*320 Inputs or Outputs*)

Clock/RAM backup battery: 3v Lithium battery

C-NET (NC-100 to NC-100): Network Type ARCNET LAN
Communications Speed 156k up to 2.5Mb per second

D-NET (NC-100 to RC-2 and IOC-16): Network Type RS485 High Speed Network
Ports Supervised RS485 ports
Communications speed 38400 bits/second

Local PC & Remote Communications: Type TCP/IP Ethernet, RS485 4 wire
Serial Port Speed Programmable 1200-38,400 baud

Real Time Clock: Built-in as standard

Watch Dog Circuit: Built-in as standard

Board Dimensions: H 7¾ in x W 5¼ in (*18.7 x 13.3 cm*)

Operating Temperature: 0 to 70°C (*35 - 150°F*)

Operating Humidity: 20 to 80% RH (*non-condensing*)

Cable Specification

PC To Controller (Ethernet):

CAT5 communications cable

PC To Controller (RS485):

Twisted pair, shielded, stranded 18 to 22 AWG

Maximum Cable Length

4000 feet (*1200 meters*)

NCNET:

Twisted pair, shielded, stranded 20 to 22 AWG

Maximum Ring Section Cable Length

2500 feet (*750 meters*)

Maximum Total Ring Cable Length

10000 feet (*3000 meters*)

D-NET:

1 twisted pair, shielded, 20 to 22 AWG

Maximum Ring Section Cable Length

3000 feet (*900 meters*)

Maximum Ring Length

15000 feet (*4600 meters*)

RC-2 to Reader:

20 to 22 AWG, 6 or 8-conductor, stranded, shielded (*not twisted*)

Maximum Cable Length

22 AWG Cable 250 feet (*75 meters*)

20 AWG Cable 500 feet (*150 meters*)

Input / Output Port Circuit Loop:

2-conductor, 20 to 22 AWG

Maximum Cable Length

1000 feet (*300 meters*)